

Manual

High Availability Report / Uptime report



Table of Contents

- 1 RANGE OF FUNCTIONS AND LAYOUT2
- 2 STEP BY STEP INSTRUCTIONS5
- 3 SUMMARY21

These instructions explain how to create a High Availability Report (Uptime report) in the GridVis desktop.

Content

- ▪ Range of the high availability report functions.
- ▪ Configuration of the high availability report in the GridVis desktop.
-
- ▪ Carry out the export.

1 Range of functions and layout

The **high availability report** evaluates the events of the type **undervoltage**. An event of the type undervoltage is evaluated as an outage in the report. **Availability** and **outage time** of each individual phase of a measurement device are analyzed and clearly shown in this report. The availability is displayed in % and in seconds. Optionally, details for each individual measuring point can be attached to the report.

An **Outage Matrix**, **XY Chart** of each phase and lists of **Simultaneous Events** can be optionally displayed in the report.

By presenting simultaneous events in lists, correlations can be seen and conclusions can be drawn about the cause of outages. The affected phases are displayed in the lists so that it can be very quickly discerned **which phase** was affected most severely or even which was affected first. The chronological preparation of the events offers the possibility to understand correlations and causes of outages.

Using the **Outage matrix**, the user can very quickly discern which measuring points have been affected most severely and when the outages occurred. An evaluation according to number of outages can also be performed in the outage matrix. If the number of outages exceeds an established threshold value, the measurement device is marked as failed.

The **XY Chart** provides information about the **concentration** of the undervoltage in the individual phases.

Two important parameters for system maintenance include the mean time between failure **MTBF** and the mean time to repair **MTTR**:


- **MTBF: Mean Time Between Failure** is the mean time from one outage to the next.
- **MTTR: Mean Time to Repair** is the mean time until the measurement device is ready for operation again.

i Lorem ipsum dolor sit amet, consectetur adipiscing elit. Pellentesque at nisi sit amet eros rhoncus iaculis. Fusce arcu. Proin varius elit sed ligula iaculis euismod.

! As of version 7.3.101, the high availability report is called **uptime report**.


Hochverfügbarkeits Report

powered by Janitza®




The first section of the report includes an overview consisting of:

- An information table that contains general information, such as report type, time period and measuring points contained in the report as well as the number of events that have occurred.
- A pie chart that visualizes the ratio of the outage time and availability.
- A ranking table which lists the measuring points with the most outage events, sorted in descending order according to the number of outage events that occurred there. The table includes the device name, number of events, availability and outage time in percent and seconds as well as MTBF and MTBR of the respective measuring point. The first three measuring points are highlighted in red.




- i** A maximum of ten measuring points are listed in the ranking table.
- If the XY chart option has been activated in the export configuration, the XY chart is located in the second section of the first report page.
- For each analyzed phase where at least one event has occurred, the events are displayed in a separate chart. The length of the outage event can be read on the X-axis and the voltage measured at the time of the event can be read on the Y-axis.
- This makes it possible to recognize concentrations of events for a specific length or voltage at a glance.


2 Step by step instructions




1 Right-click the **Exports & Reports** tree item.




1 Click the **Create data export** menu item.




1 Click the **Script** dropdown button.



1 Click the **High-availability report** list item.



1 Click the **Next** button.



1 In this step, select any number of measurement devices that are to be included in the report.

Click the **Next** button to access the next step.

Create a new export config

Steps

1. Select a script
2. Choose devices
3. **Time Period Settings**
4. Define report structure
5. Set availability rating
6. Choose file to save

Time Period Settings

Report Creation

Should report creation be automated? Yes No

Time instant for Report Creation: Monatlich

Please note:
A time instant for automated creation can be added by means of GridVis Time Management

Report Timescale

Choose a timescale to be included by the report: Last 7 days

Should the current day get included? Yes No

Selected time range: 8/9/18 - 8/15/18 (12:00 AM - 11:59 PM)

< 1 Next > Finish Cancel Help

1 In the **Report creation** area, you can have the report created automatically.

In the **Report Timescale** area, you can select time periods from a list over which the report is created.

Create a new export config

Steps

1. Select a script
2. Choose devices
3. Time Period Settings
- 4. Define report structure**
5. Set availability rating
6. Choose file to save

Define report structure

Report title
High-availability report

Headline of the report

Layout settings

Display sequence of the measuring points in the report

1 sort devices alphabetically

Show logo
Select logo
No Image selected

Show Date

Show Page Number

Show Legend

Show Links
Link from Device

The devices are provided with a link to their device homepage or to a global link.

Report functions

XY Charts
Display the severity & length of the events

Outage Matrix
Matrix display at which time an event occurred

Simultaneous Events
Depending on the 'Tolerance of simultaneous events', any simultaneous events are combined into groups
Tolerance of simultaneous events 500 ms

Show calendar week

Detail Tabs
Creates a new tab for each measurement place (Excel only)

Phases relevant for the report

L1 L2 L3 L4

< Back Next > Finish Cancel Help

1 Click the drop-down button.

Create a new export config

Steps

1. Select a script
2. Choose devices
3. Time Period Settings
- 4. Define report structure**
5. Set availability rating
6. Choose file to save

Define report structure

Report title
High-availability report

Headline of the report

Layout settings

Display sequence of the measuring points in the report

1 sort devices alphabetically
sort devices alphabetically
sort devices by ranking

Select logo

No Image selected

Show Date

Show Page Number

Show Legend

Show Links

Link from Device

The devices are provided with a link to their device homepage or to a global link.

Report functions

XY Charts
Display the severity & length of the events

Outage Matrix
Matrix display at which time an event occurred

Simultaneous Events
Depending on the 'Tolerance of simultaneous events', any simultaneous events are combined into groups
Tolerance of simultaneous events 500 ms

Show calendar week

Detail Tabs
Creates a new tab for each measurement place (Excel only)

Phases relevant for the report

L1 L2 L3 L4

< Back Next > Finish Cancel Help

1 Select the order of the measuring points in the outage matrix.

Create a new export config

Steps

1. Select a script
2. Choose devices
3. Time Period Settings
- 4. Define report structure**
5. Set availability rating
6. Choose file to save

Define report structure

Report title

High-availability report

Headline of the report

Layout settings

Display sequence of the measuring points in the report

sort devices alphabetically

Show logo

Select logo

No Image selected

Show Date

Show Page Number

Show Legend

1 Show Links

Link from Device

The devices are provided with a link to their device homepage or to a global link.

Report functions

XY Charts

Display of the severity & length of the events

Outage Matrix

Matrix display at which time an event occurred

Simultaneous Events

Depending on the 'Tolerance of simultaneous events', any simultaneous events are combined into groups

Tolerance of simultaneous events 500 ms

Show calendar week

Detail Tabs

Creates a new tab for each measurement place (Excel only)

Phases relevant for the report

L1 L2 L3 L4

< Back Next > Finish Cancel Help

1 Click the **Show links** checkbox to assign the measuring point names in the outage matrix with a link.

Create a new export config

Steps

1. Select a script
2. Choose devices
3. Time Period Settings
- 4. Define report structure**
5. Set availability rating
6. Choose file to save

Define report structure

Report title

High-availability report

Headline of the report

Layout settings

Display sequence of the measuring points in the report

sort devices alphabetically

Show logo

Select logo

No Image selected

Show Date

Show Page Number

Show Legend

Show Links

1 Link from Device

The devices are provided with a link to their device homepage or to a global link.

Report functions

XY Charts

Display of the severity & length of the events

Outage Matrix

Matrix display at which time an event occurred

Simultaneous Events

Depending on the 'Tolerance of simultaneous events', any simultaneous events are combined into groups

Tolerance of simultaneous events 500 ms

Show calendar week

Detail Tabs

Creates a new tab for each measurement place (Excel only)

Phases relevant for the report

L1 L2 L3 L4

< Back Next > Finish Cancel Help

1 Click the dropdown button.

1 Select an option.

- i The **Link from device** option automatically links each measuring point with the respective device homepage.
- i
- i The **Global link** option links each measuring point with the address entered in the text field.

Create a new export config

Steps

1. Select a script
2. Choose devices
3. Time Period Settings
- 4. Define report structure**
5. Set availability rating
6. Choose file to save

Define report structure

Report title

High-availability report

Headline of the report

Layout settings

Display sequence of the measuring points in the report

sort devices alphabetically

Show logo

Select logo

No Image selected

Show Date

Show Page Number

Show Legend

Show Links

Link from Device

The devices are provided with a link to their device homepage or to a global link.

Report functions

XY Charts

Display of the severity & length of the events

Outage Matrix

Matrix display at which time an event occurred

Simultaneous Events

Depending on the 'Tolerance of simultaneous events', any simultaneous events are combined into groups

Tolerance of simultaneous events 500 ms

Show calendar week

Detail Tabs

Creates a new tab for each measurement place (Excel only)

Phases relevant for the report

L1 L2 L3 L4


< Back 1 Next > Finish Cancel Help

1 Click the **Next** button to access the next step.


The screenshot shows a software window titled "Create a new export config" with a close button in the top right corner. On the left, a "Steps" list contains six items, with the fifth item, "Set availability rating", highlighted in bold. The main area is titled "Set availability rating" and contains a section for "Assessment of overall availability". This section has two input fields: "How many events can take place per 4 hour?" with the value "1", and "How many events may take place during the whole timerange?" with the value "5". Below these fields is a "Hint" in red text: "If the number of allowed events is exceeded, the measurement place is marked as not passed." At the bottom of the window, there are four buttons: "< Back", "Next >", "Finish", and "Help". The "Next >" button is highlighted with a red box, and a red square with the number "1" is placed over the "Back" button.

1 In this step, you define how many outage events may occur per week, day or hour and how many outages may occur over the entire time period.

Click the **Next** button to access the next step.



1 The possible output formats include xls, xlsx and pdf.
Click the **File action** dropdown button.



1 Select a file action that is executed if the specified file already exists.

i **Attach a date to the file name:**


i Creates an additional file and attaches the execution date of the report to the file name.

i **Overwrite existing file:**


i Overwrites an existing report. Edits made by a user in the document are lost.

i **Modify existing file:**

i Edits the data in an existing file. Adjustments that were made in the file are kept.




1 Click the **Finish** button.




1 Enter the name here under which the export is to be saved in GridVis.


Click **OK** to complete the creation of the export.




1 Open the Exports & Reports tree item.



1 Right-click the **High_Availability** tree item.



1 Click the **Execute data export** menu item.



3 Summary

Please enter your text here.

General information

- The high availability report is created with a **data export** from the **GridVis Desktop**.
- It evaluates the **undervoltage** event recorded there.
- The individual elements of the report (XY chart, outage matrix and simultaneous events) can be activated or deactivated.

Outage matrix

- The outage matrix is a table view of the measuring points and the outages that occurred there per week, day or hour*.
- Links to the device homepage of the measuring points or of a user-defined address can be integrated here.

*Depends on the selected time period

XY chart

The length and recorded voltage of the outage events for each relevant phase are displayed in the XY charts.

Simultaneous Events

Events that occur within a time period that is defined by the user are grouped together.